

Installation Guide: Addo Wall Mounted with Standoff



The standoff system will include several strips of 9mm thick acoustic material pre-affixed to the panel and pre-drilled, plus the necessary number of drywall screws to affix the panel to the wall.

- The screws will go through the panel and the standoff and into the wall.
- While it isn't necessary to find a stud, it is recommended.



Step 1:

Mark the desired position of wall-mounted panel using a level.

Step 2:

Remove the cutout to reveal the pre-drilled holes.

Step 3:

Affix the panel to the wall using the included drywall screws.

Step 4:

Replace the cutouts to conceal the screws.

